







Battery voltages



Shore power current (A)



BMP280 baro sensor & RTC




Keypad


use internal pull-ups




Buzzer




GSM module connector



Power loss sensor




LCD backlight power




Black tank weight

NEEDS POWER SWITCH ON/OFF



DHT22 humidity monitor connector



IF panel (cont'd)

BoatPanel

not saved!

Sheet: 2/2

8