

Fuse box under port berth to the left

Fusible	Calibre		Standard	Option
F1	10A	Port hulls lights	X	
F2	5A	HIFI		X
F3	10A	Fresh water pump	X	
F4	10A	Port engine bilge pump	X	
F5	10A	12V socket/chart table light	X	
F6	10A	Navigation lights	X	
F7	15A	Port schower pumps		X
F8	5A	Navigation instrument	X	X
F9	5A	GPS / VHF		X
F10	20A	Auto Pilot		X

Fuse box behind refrigerator, access from starboard hall way closet

Fusible	Calibre		Standard	Option
F11	10A	Stb hulls lights	X	
F12	10A	Stb bilge pump	X	
F13	10A	Sea water pump		X
F14	10A	Stb engine bilge pump	X	
F15	10A	Saloon/galley lights	X	
F16	15A	Fridge	X	
F17	15A	Stb schower pumps		X
F18	10A	Port bilge pump	X	
F19	25A	Stb electric toilet		X
F20	25A	Port electric toilet		X