




House Battery Breakers

1. 15A Running Lights and Compass Circuit (4.9A)	14AWG
2. 15A Stereo (2A)	16AWG
3. 15A Autohelm (8A)	12AWG
4. 15A VHF (6A)	14AWG
5. 15A Deck Light Circuit (2A)	16AWG
6. 20A MSD Circuit (12A)	8AWG
7. 10A Steaming Light Circuit (.8A)	16AWG
8. 10A Anchor Light Circuit (.6A)	16AWG
9. 15A Depth/Speed Circuit (3A)	14AWG
10. 15A Forward Cabin Lights Circuit (4.5A)	14AWG
11. 15A Main Cabin Lights Circuit (6A)	14AWG
12. 15A Aux Plug Circuit (10A)	14AWG
13. 15A Fan (6A)	14AWG

Wire #	Break #	Description
1	1	Forward Running lights
4	4	VHF Radio
5	6	SanX Head System
8	1	Compass light
9	9	Nexus System/GPS
10	10	Port Fwd Cabin/Head Lights
11	11	Port Main Cabin Lights
12	11	Stbd Main cabin Lights
13	13	Port Fan Circuit (Main&Fwd)
14	13	Stbd Fan Circuit
15	1	Stern Running Light
16	13	Stbd Fan
17	8	Anchor Light
18	7	Steaming Light
19	5	Deck Light
20	11	Galley Light
21	13	Galley Fan
22	2	CD Player
23	3	Autohelm